

MAJIC Warmer INTMAG4046



Instructions For Use

To activate warmer, click metal disk by bending (may take several clicks). Warmer has been activated if clear liquid begins turning white and solidifying resulting in heat. To reuse, place warmer in simmering water only for several minutes until all white crystals have dissolved. Remove from water and allow to cool. Your warmer is now ready to reuse.

Note: Please ensure that all crystals have been completely dissolved before allowing to cool, as even the smallest crystal remaining will automatically reactivate the warmer.

DO NOT MICROWAVE.