

Liberty Ultraviolet Light



Please insert batteries exactly as illustrated below. If batteries are inserted wrongly, the torch will operate but the ultraviolet light **will not work**.

If the UV light does not work, follow these corrective steps in order:

1. Check that the batteries have been inserted **exactly as illustrated below**.
2. Replace batteries with new ones.
(The UV light requires a much greater voltage to operate than the torch. As the batteries start to get low, the UV light will stop working. Whereas the torch will still operate).
3. Replace the UV tube. **Reorder Code: UVT**
4. If the UV light still does not work after trying all the above steps, please return the unit.

